

### Characteristics



Pharmaceutical Applications



Cleanroom Applications



Activated Carbon



Static Dissipating



Static Dissipating Toolkit



Corrosive Recovery



ARU-15 EX (TC) Shown

- Static Dissipative and grounded
- \*Cleanroom compatible. Can be used in the pharmaceutical industry when equipped with stainless steel 4-wheel dolly or tilting cart
- Designed for the recovery of acids and corrosive liquids
- To be used as a recovery unit in conjunction with a vacuum cleaner
- Available with a Middle Ring with KINA 3® Activated Carbon (MRAC) for the adsorption of Chloride and acid vapors (HF, HCL, etc). Other types or carbon available.
- For liquid recovery
- Static dissipative acid-resistant high-density polyethylene, nylon and pvc
- Recovery capacity of 12.5 gallons (48 liters)
- Available with a 4-wheel dolly, tilting cart or hydro-cart. 4-wheel dolly and tilting cart available in stainless steel
- Includes a complete tool kit

Acid-resistant high-density polyethylene, nylon and pvc. These units were designed for the recovery of acid as well as other corrosive liquids. These units are static dissipative and conductive. These units are available on a variety of powder coated or stainless steel carts. Also available with a Middle Ring with Activated Carbon Cartridge. Different types of carbon are available for the adsorption of toxic/nuisance fumes and vapors. These recovery units are to be used in conjunction with a vacuum cleaner system.

#### U.S. Headquarters

**Tiger-Vac Inc. (USA)**  
73 S.W. 12 Ave. Bldg. 1, Unit 7  
Dania, FL 33004  
USA

Tel.: 954-925-3625

Fax.: 954-925-3626

Web site: <http://www.tiger-vac.com>

Email: [sales@tiger-vac.com](mailto:sales@tiger-vac.com)

#### International Headquarters

**Tiger-Vac International Inc.**  
2020 Dagenais Blvd.  
Laval, Quebec  
H7L 5W2  
Canada

Tel.: 450-625-0099 & 450-622-0100

Fax.: 450-625-3388

Web site: <http://www.tiger-vac.com>

Email: [support@tiger-vac.com](mailto:support@tiger-vac.com)

## Specifications for model ARU-15 EX SERIES

Name	Part Number	Wet Recovery
ARU-15 EX (HY-C) MRAC	211882	12.5 gallons
	Dimensions: N/A Weight: 0 lb	
ARU-15 EX (TC)	211871	12.5 gallons
	Dimensions: N/A Weight: 0 lb	
ARU-15 EX (TC) MRAC	211867	12.5 gallons
	Dimensions: N/A Weight: 0 lb	
ARU-15 EX CR (TC)	211875	12.5 gallons
	Dimensions: N/A Weight: 0 lb	
ARU-15 EX CR (TC) MRAC	211879	12.5 gallons
	Dimensions: N/A Weight: 0 lb	

### MRAC - Middle Ring with Activated Carbon

Activated carbon is used for the adsorption of toxic/nuisance fumes and vapors. Tiger-Vac offers a variety of activated carbons for the recovery of fuels, mercury, chloride and acid vapors and for Arsine and Phosphine.

### **Warning:**

Do not use these units to recover explosive dusts or flammable liquids